

## AIR SWITCH REMOTE CONTROLLER


- Installs into existing sink hole drilling, or countertop, to operate disposer with plunger style air switch
- Perfect application for island countertops
- No wiring connections or code restrictions
- Eliminates need for an electrical wall switch
- Simplifies first time food waste disposer installations
- Operates on 120V household wall receptacle

The AS100 and AS150 are easily installed air actuated on/off controls for Kindred Waste Disposers up to 1.0 H.P., 120V. Simply plug the unit into any standard electrical outlet and plug the waste disposer into the receptacle provided with the package. The waste disposer can be activated and deactivated by depressing an air button.

**AS100** - Stainless Steel Finish Air Button

**AS150** - Satin Nickel Finish Air Button

### DISPOSER APPLICATION (PLUG-IN)



Due to continued product improvement, system configurations and specifications may change without notice.